



PRESS RELEASE

Measuring Total Carbon for Carbon Sequestration with a field spectroradiometer

Lawrence, MA – May 15, 2018 Climate change and the rise of CO₂ in the atmosphere has highlighted the possibilities of carbon sequestration in soil. Estimating sequestration possibilities involves accurately measuring Total Carbon (TC). TC is a measure of the organic and inorganic carbon contained within soil. TC in soil is a result of the decomposition of plant and animal matter, living and dead microorganisms, roots from plants, soil biota (which includes earthworms, nematodes, fungi, protozoa, bacteria, etc.) and carbon minerals.

TC affects soil characteristics, including color, nutrient capacity (cation and anion exchange capacity) nutrient stability and turnover, and subsequently water relationships, aeration, and cultivation. The accurate measurement of TC can result in better crop management for cultivated land and better understanding of available carbon pools in uncultivated land. VIS/NIR field spectroscopy offers a fast, accurate and affordable alternative to lab analysis of TC—an alternative that works without destroying the sample. Spectral evolution's PSR+ spectroradiometer is specifically designed for spectral analysis *in situ*. It's rugged and reliable with a range of direct attached lenses as well as fiber mount options with a steel-jacketed fiber optic cable that's rugged and field swappable. A full range spectroradiometer, it covers wavelengths from 350 to 2500nm—UV/VIS/NIR.

In a typical soil spectrum, TC spectral features would be seen at 400, 1000, 1400, 1900-2100 and 2200-2400nm. To determine TC it is important to have high resolution spectra for analysis. The spectra from TC measurements are automatically saved in ASCII format and can be further analyzed using multivariate statistical tools such as PLSR and chemometrics analysis and spectral libraries built for predictive modeling of soils.

Spectral Evolution's PSR+ features high resolution and enhanced sensitivity to allow you to quickly collect clear spectra. Auto-shutter, auto-exposure, auto-dark current capabilities mean no manual optimization between scans. For soil analysis, the PSR+ can be equipped with a rugged and reliable sample contact probe, as well as a benchtop probe with sample compactor. The PSR+ is ideal for taking scans of vertical or horizontal soil layers in a pit.

Our DARWin SP Data Acquisition software gives you complete control of your instrument interface, access to vegetation indices as well as the USGS sample library, and saves all spectra and metadata as ASCII files for use with 3rd party software such as ENVI, TSG, R, Unscrambler and GRAMS. Optional EZ-ID sample identification software can help you match your target samples to the USGS, SpecMIN and GeoSPEC mineral spectral libraries to quickly identify clays. Or with the Custom Library Builder module, you can create your own soils and TC library by simply saving your metadata and scans.

NIR spectroscopy can be used in conjunction with complementary technologies, such as portable XRF where you can use the data from a PSR+ with the elemental analysis from XRF technology for a more complete picture of TC and other soil properties.

For more information:

<https://spectralevolution.com/applications/remote-sensing/carbon-sequestration/>

About SPECTRAL EVOLUTION

Established in 2004, SPECTRAL EVOLUTION is a leading manufacturer of laboratory and handheld portable spectrometers, spectroradiometers and spectrophotometers. SPECTRAL EVOLUTION spectrometers are used worldwide for many mission-critical lab and field applications in mining, remote sensing, vegetative studies, ground truthing, environmental and climate studies, developing satellite calibrations, and more, due to their reliable, robust, rugged design and user-friendly one-touch features.

EZ-ID and oreXpress are trademarks of SPECTRAL EVOLUTION.

Press contact

Mo Kashdan

Marketing & Sales

978-687-1833

Maurice.kashdan@spectralevolution.com

SPECTRAL EVOLUTION

1 Canal Street, Unit B1

Lawrence, MA 01840 USA

www.spectralevolution.com

